


## Safety instructions

- 1.If the unit is operated consecutively for more than 30 minutes, it may activate the overheat protection device and stop the operation automatically. Wait for the temperature to cool down to safe level then it can be used again.
- 2.Adjust speed according to your body status.
- 3.Do not use after meal.
- 4.Do not apply to pregnancy.
- 5.Disconnect power when the unit is not in use .
- 6.A damp cloth and neutral cleaners may be used in normal maintenance; do not use thinner or any other solvent.
- 7.Keep away from the children's reach.
- 8.Do not apply heavy articles on the unit.
- 9.Do not dismantle, repair or modify the unit yourself or by any unauthorized personnel
- 10.Do not use when outlet, cord or plug is damaged .
- 11.Do not apply to those of heart disease, malignant tumor and any injuries on the part of body that the unit is intended to use on.
- 12.Disconnect the power when not in use for a long period of time.
- 13.If you detect a malfunction or any other abnormal condition in the operation of your chair, turn off the power immediately and disconnect the power cord from the outlet. Call for technician.
- 14.Do not use if fabric cover is torn or worn out. Call technician immediately for repair.
- 15.If you detect a malfunction or any other abnormal condition in the operation of your chair, turn off the power immediately and disconnect the power cord from the outlet. Call for technician.



## Specifications

product	fitness belt
mode	KS-2008
voltage	100V-240VAC
output current	24VDC
power consumption	24W
Frequency	50/60HZ

## FITNESS BELT

# KS-2008

## Description of Product

